

トラバース面積計算書

区		28 街区		トラバース面積計算書										計算者		点検者					
番号	測点	測定内角		方位角		距離		緯距		径距		合緯距		合径距		X	Y	X + Y	倍面積		
																			+	-	
	1	8	57 00	60	30 00	55	430	27	285	48	240	0	0	48	240	(-)	33	580	14	660	
	2	178	51 52	61	38 08	14	460	6	866	12	723	27	285	48	240	60	963	0	60	963	
	3	196	28 59	45	09 09	13	870	9	778	9	833	34	151	60	963	70	796	(-)	48	240	
	4	197	47 39	27	21 30	12	270	10	895	5	637	43	929	70	796	76	433	(-)	60	963	
	5	184	26 12	22	55 18	10	130	9	328	3	945	54	824	76	433	80	378	(-)	70	796	
	6	141	21 58	61	33 20	4	014	1	911	3	529	64	152	80	378	83	907	(-)	76	433	
	7	70	02 20	171	31 00	10	380	10	268	1	530	66	063	83	907	85	437	(-)	80	378	
	8	255	50 00	95	41 00	29	630	2	939	29	482	55	795	85	437	114	919	(-)	83	907	
	9	89	45 20	185	55 40	17	036	16	947	1	760	52	856	114	919	113	159	(-)	85	437	
	10	152	36 20	213	19 20	23	640	19	757	12	988	35	909	113	159	100	171	(-)	114	919	
	11	153	26 20	239	53 00	12	377	6	212	10	707	16	152	100	171	89	464	(-)	113	159	
	12	147	09 00	272	44 00	55	945	2	656	55	884	9	940	89	464	33	580	(-)	100	171	
	13	203	17 00	249	27 00	35	860	12	596	33	580	12	596	33	580	0	89	464	(-)	89	464
	計																				
																			7647	860	
																			2701	108	
																			4946	752	
																			2 =	2473	
																			2473	276	

トラバース面積計算書

28 街区

点検者

[illegible]